



---

# INVISACOOK

*The Original*

---



INVISACOOK RAIL INSTALLATION GUIDE

# Parts and Pieces that come with the Rail Installation Pack




8 Pieces of 16mm Button Head Socket Cap Screws, Stainless Steel 18-8 (304), Black Finish, for Aluminum Profile of L-Bracket to T-Bar



8 Pieces of T Sliding Nuts Hammer Nut Block Square Nuts M5 T Nuts for Aluminum Profiles of L-Bracket to T-Bar



8 Pieces of Wood Screws 3/4 Inch (20mm), Premium Flat Head Phillips Black Wood Screws, Self Tapping Electrophoresis Used in Indoor Furniture, Woodworking For screwing the L-Bracket into cabinet wall.




2 Pieces of 22" (560mm) Miter T Track



4 Pieces of 11" (280mm) T-Bar with Designated holes for L-Bracket assembly



4 x Corner Bracket 78x78mm for Aluminum Extrusion Profile, 4 Hole Inside Strong Support Corner Brackets



## Included Parts and Pieces:

**2 x 22" (560mm) Anti-Vibration Strips**

**2 x Miter T-Track, T-Bar and Corner Bracket Assembly**


**8 x 3/4" (20mm) Wood Screws**

# IMPORTANT NOTES FOR PROPER INSTALLATION BY GUIDANCE OF PORCELAIN MANUFACTURES


- Burners are to be a **minimum of 25cm or 10" Inches** away from any open ends or Edges of the Countertop Material.

**\*\*See diagram below\*\***

- All corners are to be round edges as instructed by the Materials Specification for the Porcelain fabricated slabs.



*Invisacook can only be used with a minimum countertop thickness of 12mm (1.2cm) (1/2") and Max thickness of 20mm (2cm) (3/4") Countertops from tested and approved brands*





**5 Burner 220V**


**8150-256-001B**



## 5 Burner Framed in Installation of Rail for Island Use Only

25cm must be met from center to  
Burners to any countertop edge

Min Countertop Depth  
is 29" (73.5cm)



With this set back in the cabinet  
of the brackets, distance from  
edge is met!






# 4 Burner Squared 220V

8140-257-001B



## 4 Burner Framed in Installation of Rail for Island Installation Only






# 4 Burner Straight Row 220V

8145-257-001BSR



## 4 Burner Straight Row, Framed in Installation of Rail in Galley Kitchen Use or Island

25cm must be met from center to Burners to any countertop edge






**3 Burner 220V**

**8134-256-001B**



## 3 Burner Framed in Installation of Rail in a Galley Kitchen

25cm (10 inches) must be met  
from center to Burners to any  
countertop edge



With this set back in the cabinet  
of the brackets, distance from  
edge is met!






**2 Burner 110V or 220V**

**8121-257-001B**




**2 Burner Framed in  
Installation for Rail in  
Island Use Only**



## 2 Burner Framed in Installation of Rail System for Galley Kitchen Use

25cm (10 inches) must be met from  
center to Burners to any countertop  
edge






**1 Burner 110V or 220V**

**8113-256-001B**



## 1 Burner Framed in Installation of Rail System for Galley Kitchen


25cm (10 inches) must be met from center to Burners to any countertop edge



## 1 & 2 Burner Framed in Installation for Rail in Cabinets smaller than 22" much be installed Vertical

Countertop back side edge  
must meet the 25cm from  
center of burner


Countertop back side edge  
must meet the 25cm from  
center of burner



With this set back in the cabinet  
of the brackets, distance from  
edge is met!

With this set back in the cabinet  
of the brackets, distance from  
edge is met!





18mm  
.25 in (6 mm) from top of cabinet frame

**Step 3**  
Screw in corner brackets  
to cabinet frame.